

Outputs

Wired and 1100 Series Wireless Outputs may be programmed and controlled. If no outputs are programmed, a No Outputs Available message is displayed.

Control an Output

Click the Outputs button and the list of programmed outputs displays. You may control each output individually by turning them On or Off or control all outputs by clicking On or Off on All Outputs.

